



CheckMate™

Fire Department Connectors

The final move for Security!

MFG. by PLACER WATERWORKS INC. 1325 Furneaux Road, Plumas Lake, CA. 95961 (530) 742-9675

CheckMate™ comes completely assembled.
Eight (8) Bolts required at the flange connection for installation.

The shipment packaging should be removed by cutting “ONLY” on the black dotted line areas provided. Knife or box cutter use outside the black dotted line may cause damage to product finish.

Tools Needed:

Two (2) 1-1/8” Wrenches
One (1) Torque Wrench
Knife / Box Cutter to cut shipping protection.

Parts Required:

8 – 3/4”Dia Bolts (not included). Break-a-way bolts suggested.
2 - Gaskets – one on each side of Check Valve (not included).
1 – NFPA approved Check Valve and approved by local governing authority.

To Install:

1. At the base “ONLY” use knife or box cutter on the dotted line to expose only the flange.
This will expose the flange. Providing protection for the majority of the product thru the remaining installation process.
2. With one new gasket placed between the sprinkler system supply line flange and the check valve.
3. Place the second gasket on top of the check valve.
4. Use 2 (two) individuals to pick-up and set the F.D.C. in place. Then one person to hold the F.D.C stable and in place while the other installs the eight (8) 3/4”Dia. bolts & tighten to the Check Valve Manufacture’s required torque.
3. Now Installed, complete packaging removal.

